

Bearing Resistance Failure GBR+

Inhaltsverzeichnis

Application options	2
Additional option FDPro	3
Basis of calculation	4
Definition of the structural system	6
Basic parameters	6
System	7
Foundation	7
Column	7
Soil	8
Ground water	11
Surface	11
Loading	12
LoadCases	13
Single Loads	15
Line Loads	15
Area Loads	16
Design / Verifications	17
Soil mechanics	17
Extended soil mechanics dialog	19
Earth pressure (with the add-on FDPro)	20
Parameter	21
Output	22

Basic Documentation – Overview

In addition to the individual program manuals, you will find basic explanations on the operation of the programs on our homepage www.frilo.com in the Campus-download-section.

Application options

The GBR+ application is suitable for the verification of squared and rectangular foundations. External loads can optionally apply centrally or with a uniaxial or biaxial eccentricity.

The software application calculates the soil pressure underneath the four corner points and the position of the zero-line in combination with a gaping joint.

The gaping joint, the permissible bearing pressure, the sliding resistance and the position stability as well as of the resistance to ground failure are verified for the foundation.

The structural system consists of the foundation slab and optionally includes a cast-on column (or plinth) with or without eccentricity.

The user can include the following load types in the calculation:


- Single vertical load V at the column location
- Horizontal loads Hx and Hy optionally at the top edge of the column or in the foundation base
- Outer moments Mx and My
- Earth top load and an additional uniformly distributed load applying to the foundation surface without a column and additional vertical single loads applying at freely selectable points.

Standards

- DIN EN 1992
- ÖNORM EN 1992
- BS EN 1992
- NF EN 1992
- PN EN 1992
- EN 1992
- still available:
- DIN 1045-1
- ÖNORM B 4700

According to the selected reinforced concrete standard, the program automatically sets the associated foundation and ground failure standard.

- DIN EN 1997-1
- ÖNORM EN 1997-1
- BS EN 1997-1
- NF EN 1997-1
- PN EN 1997-1
- DIN 1054:1976/2005/2021



Support of all 3 verification methods according to Eurocode 7, adjustable for all national annexes.

The partial safety factors and combination equations for the geotechnical verifications can be edited.

See Design - [Parameters](#).

Additional option FDPro

With the additional option FDPro, the foundation programmes FD+/FDB+/FDS+ and GBR+ can be extended to include

- an earth pressure approach
- an inclined foundation base
- a seismic ground failure verification
- a ground failure - punching shear verification
- a bearing capacity calculation of the foundation soil with a table of design values of the base pressure resistance.
- a graphical output of the internal forces along the main axes

See [calculation basis for foundation engineering](#) in the FD+ manual.

See also ▶ [Video](#)

Basis of calculation

Position stability

For the verification of the position stability, the stabilising and destabilising moments in relation to the outer edges of the foundation are calculated in combination with the Eurocodes. If you use the result load cases instead of the characteristic ones, they are used in the calculation of the stabilising and destabilising moments without consideration of reduction factors. In this case, only self-weight is multiplied with the partial safety factors that have a favourable or unfavourable effect.

Gaping joint

Under permanent loading, no gapping joint must occur and under the total loading, gapping of the foundation joint is allowed up to the centre of gravity. In combination with Eurocodes, the calculation of the gapping joint is based on representative loads instead of characteristic ones.

If you use result load cases instead of superpositions (Basic parameters ▶ Type of loading), the loads are reduced to the characteristic level with the help reduction factors before examining the gapping joint. In this connection, it is important to define whether the individual load cases are the result of permanent loads exclusively or of both, permanent and variable loads: a gapping joint up to the centre of gravity is only permitted for the combination of permanent and variable loads. It is not permitted if only permanent loads apply.

Permissible bearing pressure

For a simplified verification in standard cases, the existing bearing pressure is compared to the permissible one. The permissible bearing pressure can be determined automatically with the help of standardised tables for the simplified verification. You can increase or reduce the permissible bearing pressure taken from the standard tables if the corresponding border conditions, such as the required anchoring depth, ground water or the relation of the horizontal and vertical loads, require this. In combination with Eurocodes, the calculation of the equivalent area for the design value of the bearing pressure is based on representative loads instead of characteristic ones.

If you use result load cases instead of superpositions, the loads are reduced to the characteristic level with the help reduction factors before examining the equivalent area. The design value of the bearing pressure is obtained by dividing the design value of the vertical loads by the representative or characteristic equivalent area. As additional information, the software determines the inclination of the characteristic or representative bearing pressure resultant in order to check whether the inclination is suitable for a simplified verification.

Stability against sliding

If horizontal forces apply, the stability against sliding is verified. It is considered satisfactory if $T_d \leq R_{td}$.

T_d : design value of the loads applying in parallel to the bottom of the foundation.

T_d is calculated by the software by multiplying T_k with the partial safety factors for the decisive limit state. The software uses the partial safety factors for the permanent and quasi-permanent design situations. If you define loads by accidental actions or earthquakes, the accidental and earthquake design situations are taken into account as well.

R_{td} : design value of the sliding resistance.

R_{td} is calculated by dividing R_{tk} by the partial safety factor for the sliding resistance for the decisive limit state in accordance with the currently selected foundation standard.

Safety against ground failure

In combination with Eurocodes, the ground failure safety is calculated with characteristic or representative values. The design values of the ground failure resistance are determined by dividing the characteristic values by the partial safety coefficients. They are compared to the design values of the actions, which are multiplied by partial safety factors. Depending on the selected design standard, the characteristic or representative ground failure safety is calculated on the basis of ÖNORM B 4435-2 or DIN 4017.

The FD+, FDB+, FDS+ and FDR+ applications always calculate the ground failure safety as an isolated foundation. FDS+ and FDR+ calculate the ground failure safety as a strip foundation if the wall length corresponds to the foundation length.

In the GBR+ application, the "strip foundation" verification type is optionally available. When you select this type of verification, all shape coefficients and the load inclination coefficients 'ma' and 'mb' are set to 1.0. Instead of the arithmetical equivalent width in the longitudinal wall direction (y-direction) the foundation length (y-direction) is taken into account.

Definition of the structural system

The definition of properties and control parameters is done in the menu on the left side of the screen. You can check the effect of the entered values in the graphical representation on the right screen section. Before the first entry, you can change the units of measurement (cm, m ...) via File ▶ [Settings](#) if required.

Wizard

The [Wizard](#) appears by default/automatically when the program starts, but can be switched off.

Input options in the 3D graphics

The description of the input options in the graphic window is given in the Document "[Basic operating instructions PLUS](#)".

Basic parameters


Type of actions

Design values	the loads shall be defined with their partial safety factors. Under particular conditions, these values are reduced by reduction factors for the foundation analyses.
Characteristic	the loads are specified with the characteristic (1.0-fold) value.
Soil bearing resistance	If the option is selected, only the bearing capacity of the soil is output in the form of a table with the design values for the bearing pressure resistance.

Standard reinforced concrete

Selection of the desired reinforced concrete standard.

The corresponding [foundation standard](#) is displayed in the graphics window at the top left



System

System

Foundation Type

Here you select the desired foundation shape

- Rectangular foundation
- Strip foundation


which influences the shape coefficients in the bearing failure verification.

See also [Basis of calculation](#).

Location foundation

The global position related to the foundation axis is only required for communication with other programs such as GEO and SBR+.

Remarks

Click the button  to enter your own [comments](#) about the system.

Foundation

In the foundation ground plan, the x-axis (positive) runs from the left to the right and the y-axis (positive) from the bottom to the top.

Width x foundation dimension in x-direction

Length y foundation dimension in y-direction

Height z foundation height

Average anchoring depth d Lowest foundation depth below the ground level or the top edge of the basement floor.

Density γ gamma concrete

Base inclination and a 4-sided different [surface definition](#) are possible with the additional option [FL+ PRO](#).

Column

Width x width of the column


Thickness y thickness of the column

Height z height of the column

Eccentricity

Eccentricity x Column eccentricity in x-direction.


Eccentricity y Column eccentricity in y-direction.



Soil

Soil properties

Determination $\sigma_{R,d}$	Select whether the design value of the bearing resistance should be entered <u>directly</u> , or to come from a standard table (<u>DIN 1054</u>) or from a user defined (<u>own</u>) table - see section below.
Load-bearing resistance $\sigma_{R,d}$	Specification of the permissible bearing pressure $\sigma_{R,d}$
Permissible settlement	Permissible settlement for comparison with the calculated settlement and presentation of the utilisation of the settlement verification.
Eff. friction Angle φ'	Angle of the inner friction underneath the foundation base.
Soil friction angle	The soil friction angle is relevant for the sliding safety check. If the angle of friction δ is not determined separately, the characteristic angle of friction $\phi'k$ may be used instead of the critical angle of friction for in-situ concrete foundations. A value of 35° must not be exceeded. The same applies to prefabricated foundations if the precast elements are laid in the mortar bed. If the prefabricated foundations are smooth and without a mortar bed, the characteristic soil friction angle $\delta k = 2/3 \phi' k$ shall be used.
Load tilt	Enter the maximum tilt of the characteristic or representative bearing pressure-resultant H/V, which should be checked in the case of simplified verification. Otherwise, default values are used.
Dialog/Table	If the determination $\sigma_{R,d}$ is not specified directly, the design value of the bearing pressure resistance is taken from a table (standard or user defined) Click the "open"/"edit" Button to open the table dialog.



Soil properties		
Determination	$\sigma_{R,d}$	DIN 1054:2021
cross section resistance	$\sigma_{R,d}$	direct specification
permissible settlement	s, adm.	DIN 1054:2021
Effective friction angle	φ'	[°] 32.5
Soil friction angle	δk	3/3 φ
Soil friction angle	δk	[°] 32.5
Dialog		open
First soil layer		
Stroke weight	γ	[kN/m ³] 17.00
Buoyant unit weight	γ'	[kN/m ³] 10.00
Effective friction angle	φ'	[°] 32.5
Cohesion	c'	[kN/m ²] 0.00
Dialog		open

Parameters by standard table DIN 1054:

According to Annex The soil pressure is taken from the corresponding table in the soil engineering standard or its National Annex.

Consistence consistency of soil: rigid, half-solid, solid – only with tables A6.6. to A6.8.

Increase (geometry) The permissible bearing pressure can be increased by 20 % if the relevant border conditions (b/d) specified by the applicable standard are satisfied. By ticking this option the value can be edited.

Increase (strength) The permissible bearing pressure is increased by 50 %, if the soil is sufficiently solid. By ticking this option the value can be edited.
Note: The values are added up under particular conditions (70 %). The subsoil has sufficient strength down to a depth below the foundation base that corresponds to twice the width of the foundation, but at least down to a depth of 2.0 m. The program checks whether an increase in the design value of the bearing pressure resistance is permissible and then applies this.

Bearing pressure resistance		
Soil properties		
According to Annex		Table A6.8
Consistence		rigid
Increase (geometry)	[%]	20.0 <input type="checkbox"/>
Increase (strength)	[%]	50.0 <input type="checkbox"/>
Anchoring depth	d [m]	1.00

Anchoring depth d Lowest foundation depth below the ground level or the top edge of the basement floor.

From own table

Create: Generates a table with design values of the bearing pressure resistance from several parameters.

Edit: Open the dialog to enter the design value of the bearing pressure resistance σ_{Rd} . The value σ_{Rd} should come from a geotechnical report and should have sufficient guarantees against ground failure and a sufficient limitation of settlements. Furthermore, the corresponding foundation width and anchoring depth must be specified.

The meaning of the other buttons can be seen from the [Tooltips](#).

First soil layer

In this section you can enter the values of the first soil layer.

For additional soil layers click the Button "Dialog – open".

Stroke weight γ Specific weight of the soil.

Buoyant unit weight γ' Specific weight of the soil layer under buoyancy. This value is only used if [groundwater](#) was defined (▶ System ▶ Soil)

Friction angle φ' Friction angle of the soil in this layer.

Cohesion c' Soil cohesion.

Further soil layers / additional values (▶ Dialog „open“)

Library	Cat.	Name	Icon	γ [kN/m ³]	γ' [kN/m ³]	φ' [°]	c' [kN/m ²]	xU' [m]	v	E_m [kN/m ²]	PI [kN/m ²]	α	q_c [kN/m ²]	E' [kN/m ²]	Procedure	E^* [kN/m ²]	E_s [kN/m ²]	x	k_s [m/s]	both sides drained	$C\alpha'$
Table	-	-	-	17.00	10.00	32.5	0.00	2.00	0.20	6000.00	700.00	0.50	1000.00	3500.00	direct specification	4946.00	2473.00	0.50	1E-07	<input type="checkbox"/>	0.003
															direct specification from constrained modulus						

Table Defined layers/values can be selected via a soil layer library.

Category Soil category according to Annex A of standard NF P94-261. It is important for the bearing capacity calculation from values of the pressiometer test according to Annex D of NF-P94-261.

Name A name for the soil layer can be assigned here.

Symbol An abbreviation for the soil layer can be assigned here.

xU thickness of the soil layer. Soil layers smaller than 0.10 m are not provided.

v The Poisson's ratio defines the ratio of a change in thickness to a change in length as soon as a stress is applied. The Poisson's ratio or transverse contraction coefficient has the formula ν or μ . It is one of the elastic material constants and bears the name of the physicist Siméon Denis Poisson.

E_m Define the pressiometric modulus according to Ménard here. It is needed for the settlement calculation from data of a pressiometer test.

PI The representative value of the limit pressure according to Ménard in the foundation base of the shallow foundation.

α Rheological factor for settlement calculation from results of a pressiometer test.

q_c The peak pressure resistance comes from the pressure test and derives modulus of elasticity and friction angle for base failure and settlement calculation.

Settlement analysis

Procedure	Direct specification or from constrained modulus: To define the compressibility of the soil (Emodule) select - directly in E* or - from the constrained modulus - Em will be calculated from stiffness/constrained modulus Es and correction factor x (from DIN 4019 T1).
E*	Compression modulus. The compressibility of the soil can be specified by a pressure settlement line or calculated from the constrained modulus in connection with a correction factor.
Es	Stiffness/constrained modulus.
x	Correction factor.

Soil layer		
Settlement Analysis		
Procedure	direct specification	
Compresses modulus E*	[kN/m ²]	4946.00
Stiffness module Es	[kN/m ²]	2473.00
Correction factor x		0.50
Settlement analysis: Consolidation		
Permeability factor k	[m/s]	1E-09
Both sides drained		<input type="checkbox"/>

Settlement analysis: Consolidation

ks	Permeability coefficient of the rate of consolidation. The value can be extracted from the soil report.
Both sides drained	For the calculation of the time to approximate decay of consolidation settlement in unilateral drainage the full layer thickness is set, in bilateral drainage only half the layer thickness.
C α'	The creep coefficient C α' can be determined from a time-settlement test according to DIN 18135. Usual value range 0.001 to 0.00001.

Ground water

- Ground water existing This option allows you to define whether groundwater exists (displays the entry "Ground water").
- Ground water Only if ticked option "Ground water existing".
Absolute depth of the groundwater below the bottom edge of the foundation body.
Negative values can be used to define a groundwater level below the base of the foundation.

Surface


- Anchoring depth Anchoring depth of the foundation body.
- Additional Terrain load Additional characteristic permanent area load on the bearing failure figure, which increases the characteristic punching shear resistance.
- Slope The ground level can be modeled as horizontal, with a continuous slope, or with a broken embankment.

Continuous:
Here you can define the slope and a berm - see [extended soil mechanics dialog](#).

Broken:
Input of the embankment sections. The "+" symbol creates a new table row for a further section. Parameters are length, height or inclination or rise (the height adjusts automatically to the incline)

Four-sided different terrain definition with the additional option FDPro

With an existing FDPro license, the terrain can be defined differently for each of the four foundation faces. To do this, remove the tick from the "All around the same" option – the entry will be extended accordingly.



Loading

Eigengewicht γ

Automatische Berücksichtigung des Eigengewichtes. Bei Grundwasser oberhalb der Sohle lässt sich das Eigengewicht nicht deaktivieren.

H loads base

Option not ticked:
The horizontal loads apply at the top edge of the base and generate a moment with a particular lever arm

Option ticked:
The horizontal loads apply directly in the base joint without generating a moment.

Delete horizontal loads



Delete all horizontal loads with one click!
This is useful if many load cases from other applications (GEO, B5...) have been imported.
Note: The horizontal loads of the individual load cases can be found/entered under the following point "Load Cases".

Right-hand coordinate system (new standard)

Coordinate system based on the right-hand rule, also referred to as right-hand coordinate system. The signs comply with the sign definitions in engineering mechanics. Positive moments about the x-axis generate pressure on the bottom and/or in the negative area of the foundation. Positive moments about the y-axis generate pressure on the right and/or in the positive X-area of the foundation. If this option is unchecked (default setting until recently) positive moments generate pressure on top right and/or in the positive X/Y-area of the foundation. In the graphic representation, both variants are shown with their absolute values. The arrows indicate the actual direction of action. The values in the data entry fields and in the output documents are indicated with their signs. If you change the sign definition, the sign of the moments about the y-axis changes as well.

Accidental snow load


When you check this option, snow loads are automatically included as accidental action in addition to the typical design situations. The user can either specify a freely selectable load factor for the accidental snow loads or have it determined automatically by the software. The default value is 2.3



Remarks


The remarks editor is called up via the  button. This text appears in the output.

LoadCases

Enter the data of the first load case via the data-entry mask or directly in the load case table, which can be displayed by activating the  tab (below the graphic).

Load case toolbar:  1/2

See [Data entry via tables](#)

To add additional load cases, click on the  button once more (a new empty input mask is displayed each time).

Tip: A description is displayed in the status line each time you click into an input field.

Column Loads

Description	Optional text to the selected action can be entered. This text is included in the output.
Action	The appropriate actions can be selected from a list: Permanent loads ... seismic loads (calculation method "characteristic").
Vertical force in z	Vertical force in the centre of the column
Moment about x/y	Positive moments generate pressure on top right or in the positive x/y section of the foundation.
Horizontal Force in x/y	Horizontal loads apply to the top edge of the foundation or the top edge of the column, if a column height was defined. These horizontal loads generate moments on their way down to the foundation base, which are taken into account automatically by the software.


If "Design values" was selected under [Type of actions](#), the following input fields appear:

Type	G/G+Q. For consideration in the calculation of the gapping joint. For permanent loads no gapping joint may occur, for permanent and variable loads the gapping joint may reach the foundation centre point at the most. For permanent loads from 2nd order theory only, the gapping joint is also tolerated up to the centre of the foundation.
Limit state	STR - internal failure of components e.g. bending measurement. GEO - failure of the foundation soil e.g. bearing resistance failure. EQU - Loss of stability. UPL - Verification against uplift or floating. SLS - Verification of serviceability e.g. settlement or verification of gapping joints. The limit state together with the design situation provides sufficient information for the safety factors to be used. If there are no 4 load cases with the same designation for the limit states STR/GEO-2, EQU, UPL and SLS, missing load cases are automatically generated with the help of the reduction factors. For some basic construction verifications, the limit states SLS and STR/GEO-2 are required simultaneously. Missing limit states are generated by offsetting with reduction factors. SLS x reduction factor = STR/GEO-2 and STR/GEO-2 / reduction factor = SLS.
Design situation	Selection of the design situation (permanent, temporary, exceptional, earthquake).

Reduction factors

These input fields are enabled if "Design values" was selected as [calculation method](#).

Reduction Factor N	Reduction coefficient for the forces acting in the z-direction (axial force in the column) and loads (additional concentrated loads, line loads and surface loads).
--------------------	---



The screenshot shows the software interface. On the left, the 'Properties' panel is open, showing a tree view with 'Loading' expanded to 'Load Cases'. Below this, the 'Load Cases' table is visible, showing a toolbar and a table with columns for 'Description' and 'Load case 1'. The table contains several rows for different actions like 'Vertical force in z', 'Moment about x', etc., with their respective units and values. Below the table, there is a 'Group membership' section with 'Simultaneous group' and 'Alternative group' both set to 0.

Reduct. Factor Others Reduction factors for other internal forces. If a column was designed in a second order analysis, the internal forces are only available on the design level. In order to make verifications in soil engineering available on the characteristic level, the reduction factors are used to adjust the internal design forces to a characteristic level. When using the characteristic calculation method (▶ [Basic parameters](#) ▶ [Calculation method](#)) in combination with first-order columns, the afore-mentioned situation does not occur.


Group membership

The assignment to a group is displayed if "characteristic" has been selected under ▶ [Basic parameters](#) ▶ Type of actions.

Simultaneous (concurrent) group

Loads of a particular action group can be defined as "always acting simultaneously" by assigning them to simultaneous (concurrent) groups.

III.: *Example for the functioning of alternative and simultaneous groups*



Alternative group

Different variable load cases with similar actions can be assigned to an alternative load case group via the allocation of an [alternative group number](#). Only the decisive load case of this alternative load case group is invoked in the superposition.


Bearing pressure / Actions from the column


Display of the bearing pressure pattern

To ensure traceability, the bearing pressure pattern with stress can be shown for all load cases and superpositions decisive in the verifications. Click the symbol "Bearing pressure" to display the graphic in a popup window. See also ▶ Design ▶ [Soil mechanics](#).



Single Loads


Define a new concentrated (single) load by activating the  button (the corresponding input mask is displayed).

Activating the  tab displays the "Single load table" giving an overview of the defined loads.

Toolbar:  - see also [Data entry via tables](#)


Tip: A description is displayed in the status line each time you click into a particular input field.

In all LC: For "[Type of actions](#)" = design values: if the option is marked, the concentrated load acts in all load cases.


Nz,k Value of the axial force of the additional single load. By clicking on the arrow icon  you can access a load value summary - see the description of the LOAD+ application.

at ax/ay Position of the additional single load in x or y direction referenced to the foundation centre.

Active in LC Assignment of the additional single load to load cases.

Activating the button  displays a dialog with the corresponding options.

Notes: *If a single load is assigned to one or several load cases it acts only in combination with the load case(s).*
In the case of the calculation method [design values](#) single loads are processed with the corresponding [reduction factors](#).
Single loads that are not assigned to load cases are not taken into account in the calculation.
All verifications are referenced to the column loads. Additional single loads are defined only to check the effects on the bearing pressure, tilting, position stability, sliding and ground failure.
For the verification of punching shear resistance, the loads that apply in the area of the punching cone must be summarized to a resulting load, because the shear design would be unsafe otherwise.
With foundations for twin columns you should combine both columns to a single column instead of defining the second column as an additional single- or line load. Otherwise, you will obtain incorrect results in the verification of punching shear resistance .



Line Loads

General operation as described under single loads.

In all LC: For "[Type of actions](#)" = design values: if the option is marked, the load acts in all load cases.

P1,k Value at the begin of the line load.
 Alternatively, the type of action can be changed to 'Design values' in the [basic parameters](#). If parts of the line load are located in examined circular sections of the punching shear check, these are taken into account when determining the shear stress. No extra punching shear check for a wall end or similar is carried out for the line loads. The punching shear check always refers to the column load.


at x1/y1 Position of P1 relative to the foundation center

P2,k Value at the end of the line load

at x2/y2 Position of P2 relative to the foundation center

Active in load case As described under single loads


Area Loads

In all LC:	For " Type of actions " = design values: if the option is marked, the load acts in all load cases.
Loads by soil on the foundation	Height of the earth surcharge, if applicable. In combination with the weight density γ , the soil load generates an area load on the foundation, which is taken into account in the calculation. <i>Explanatory note: The earth surcharge load refers to the top edge of the foundation. If a wall, column, wall base or pocket exists, the earth surcharge load is reduced in accordance with the geometry of the structural component.</i> <i>Note: This value has nothing to do with the self-weight of the foundation.</i>
Density γ, k	Weight density of a possible soil load.
Area Load q, k	Additional area load on the foundation body. <i>Explanatory note: The area load acts on the surface of the foundation. If a wall, column, wall base or pocket exists, the area load is reduced in accordance with the geometry of the structural component. If a top-mounted pocket exists, the area load also acts on the pocket, but not in the area of a column casted in the pocket. See the description of the option "Earth surcharge height" for more information.</i>
Active in load case	Assignment of the additional area load to load cases. Activating the button  displays a dialog with the corresponding options.

Design / Verifications



Settings

Earthquake: $\Psi_2=0.5$	In accordance with the introductory decree of DIN 4149 for Baden-Württemberg, the combination coefficient $\Psi_2 = 0.5$ for snow loads should be used in the superpositions with seismic loads.
Round out...	This setting only affects the graphic representation of the course of the internal forces. It has no influence on the calculation results.
Transient situation	When you check this option, the transient design situation is used. When you uncheck the option, the persistent situation is used. The accidental situation and the seismic situation are automatically considered if corresponding actions have been defined.



Soil mechanics

Proof format	<p>Define here whether a</p> <ul style="list-style-type: none"> - simplified verification, an - exact verification or a - user-defined verification <p>is to be carried out.</p> <p>The <u>simplified verification</u> includes compliance with the design value of the bearing resistance with limitation of the inclination of the load resultants. The <u>exact verification</u> format includes a foundation failure verification, a sliding safety verification and a settlement calculation.</p>
Checks soil engineering	<p>Click on this symbol to open the extended dialog with graphical illustrations for bearing failure, bearing pressure and settlements.</p> <p>You can also open the extended dialog directly in the toolbar with the bearing pressure symbol (<i>note: if only the simplified verification is carried out, only the "Bearing pressure" tab is displayed</i>).</p>



User-defined proof format

All verification options are offered here for individual selection.

Resulting bearing pressure	Requirement for the simplified verification: the inclination of the characteristic or representative bearing pressure resultant complies with the condition $H/V < 0.2$.
Bearing resistance	The verifications for the ground failure and sliding limit states as well as the serviceability (verification of settlements) are replaced by the use of empirical values for the design value of the bearing resistance.
Limitation of eccentricity	Verification according to NF P 94-261 13.3 for the eccentricity of the load.
Scope of verification	In a separate dialogue, you define whether the limit states and design situations according to the

	selected standard are to be used for this verification or whether they are to be adapted individually (user-defined).
Proof of sliding capacity	When the load vector is not perpendicular to the base surface, the resistance of the foundations against sliding in the base area must be verified.
Seismic	With the add on FDPro: run a seismic bearing capacity detection according to DIN EN 1998-5: 2010 Annex F.
Depth factor	The depth coefficients take into account the favorable influence of the shear strength in the fracture joint above the base of the foundation in the bearing failure analysis. In some European countries, this effect can be taken into account with coefficients > 1 .
Calculate settlement	For the settlement analysis, the compression of the soil should be taken into account down to the settlement influence depth t_s . The depth t_s may be assumed at the level at which the additional perpendicular stress generated by the mean settlement effective load has an amount of 20% of the effective vertical output stress of the soil.
	One of 5 calculation methods can be selected.
Gaping joint	Optional verification of the gaping joint.

without
 Settlement equations
 Stress integration
 from pressure meter test data
 from cone penetration data
 adapted elasticity procedure

Extended soil mechanics dialog

Calling up the dialogue on "checks soil engineering (exact/simplified verification)."

Ground failure

Seismic/Earthquake zone: call up the earthquake dialog.
Selection of the partial safety factor γ_{Rd} .

Surface

The following input parameters are displayed via the "Surface" button:

Anchoring depth Lowest anchoring depth below terrain/ top of basement sole.

Slope The ground level can be horizontal, with a continuous slope, or with a broken embankment.

Berm The width of berm is the distance between the outer edge of the foundation and the beginning of the slope.


Inclination β The terrain inclination indicates the angle of inclination of a slope from the defined berm. The inclination affects the ground failure verification and defines exclusively downsloping terrain.

Additional terrain load An additional characteristic permanent area load on the bearing resistance figure can be entered here, which increases the characteristic punching shear resistance.

Ground water

Groundwater exists See System ▶ [Groundwater](#).

Groundwater Depth See System ▶ [Groundwater](#).




Settlement

Representation of the course of settlement and stress over the depth as well as graphic representation (diagrams of settlement) of the course of settlement over time, the settlement and influence coefficients per selection list.

Calculate settlement see page before

Settlement $G_k, j...$ Settlements can be calculated with permanent loads or with permanent and variable loads.



Bearing pressure

Display of the bearing pressure pattern in 2D/3D. Selection via the top selection line.

For entries/changes, see the chapter System ▶ [Soil](#).

Earth pressure (with the add-on FDPro)

Enables the application of earth pressure.

See [FDPro](#)

Bearing Pressure

Simplified check
Simplified check
Gaping joint permanent loads only
Gaping joint permanent and variable loads
Ground failure

Properties	
Basic parameter	
System	
Loading	
Design	
Soil Mechanics	
Earth pressure	
Parameter	
Output	

Earth pressure	
Use earth pressure	<input checked="" type="checkbox"/>
Wall friction angle δ_a	2/3 φ
Passive earth pressure enabled	<input type="checkbox"/>
Earth pressure type	
Earth pressure type	Active earth
Increased active earth pressure	<input type="checkbox"/>
apply tensile forces from cohesion	<input type="checkbox"/>
Apply minimum earth pressure	<input checked="" type="checkbox"/>
Apply compaction pressure	<input type="checkbox"/>

Parameter


User defined

Mark this option if you want to change the safety factors and design rules that deviate from the set standards.

The corresponding input fields/editing buttons are then displayed.

Use the "Edit" button to open the respective tables for changing the values - the information texts for the individual parameters are displayed in the lower window area when you click in an input field.

- Support of all 3 verification methods according to Eurocode 7, adjustable for all national annexes.
- The partial safety factors and combination equations for the geotechnical verifications can be edited.
- Since all table values can be changed, the standard setting for a specific country (e.g. India, Sweden, etc.) can be easily defined.



General Settings		
User defined		<input checked="" type="checkbox"/>
User defined values	->	Edit
User defined values	->	Default valu
All safety factors		Edit (53)
Combination equations		
Verification procedure	1	Edit (2)
Verification procedure	2	Edit (2)
Verification procedure	3	Edit (2)
Failure of structures and components		
Action/Strain	STR A	Edit (4)
Material resistance	STR M	Edit (2)
Failure of subsoil		
Action/Strain	GEO A	Edit (10)
Material resistance	GEO M	Edit (10)
Lad resistance	GEO R	Edit (6)
Stability		
Action/Strain	EQU A	Edit (4)
Material resistance	EQU M	Edit (5)
Float up		
Action/Strain	UPL A	Edit (4)
Material resistance	UPL M	Edit (5)

Output

Output scope / options

By checking the desired options, you can determine the scope of output.

Font size and scale can be adjusted for the graphic.

Output as PDF document

The Document tab displays the document in PDF.

See also [Output and printing](#).

Properties

- Basic parameter
- System
- Loading
- Design
- Output
 - General
 - Soil Mechanics

Output

Output scope	User defined
EQU - Stability	
Static equilibrium	<input checked="" type="checkbox"/>
UPL - Uplift	
SLS - Serviceability - simplified verifications	<input checked="" type="checkbox"/>
Resulting bearing pressure	<input checked="" type="checkbox"/>
Bearing resistance	<input checked="" type="checkbox"/>
GEO - bearing capacity - precise verification	
SLS - Serviceability - precise verifications	
Text gapping joint	<input checked="" type="checkbox"/>
Graphic gapping joint	G <input type="checkbox"/>
Graphic gapping joint	G+Q <input type="checkbox"/>
Text settlement	<input checked="" type="checkbox"/>
Graphics settlement and tensio	<input type="checkbox"/>
Graphic time-settlement line	<input type="checkbox"/>
SLS - Serviceability - simplified verifications	

Document

94.5% Page 2 of 2 Start page: 1 Page layout

Pages Bookmarks

- System
 - Plan view
 - Foundation
 - Member
- Loads
 - Column loads
 - Superposition
- Results
 - Preview Checks
 - Bearing Resistance
 - Simplified method

Loads

Column loads - characteristic

No.	Act	Description	N kN	M _x kNm	M _y kNm	H _x kN	H _y kN	SIM	ALT
1	g	Load case 1	500.0	0.00	0.00	0.0	0.0	0	0
2	A	Load case 2	300.0	0.00	0.00	0.0	0.0	0	0

Self-weight is taken into account in the calculation. Density Concrete : $\gamma = 25.00 \text{ kN/m}^3$. Total Foundation without socket resp. column $20.000 \text{ m}^3 / 500.00 \text{ kN}$. Torsion from horizontal loads is not considered.

Superposition

No.	DS	Superposition
1	P	0.9 resp. 1.1 x (1)
2	P	0.95 resp. 1.05 x (1)
3	P	1.0 x (1)
4	P	1.0 x (1) + 1.0 x (2)
5	P	1.35 x (1) + 1.5 x (2)
6	P	1.0 x (1)

DS: design situation P: Permanent
The load case numbers are listed in parentheses.

Results

Preview Checks

Check	Superposition	η
Gapping joint only permanent loads	3	0.00
Gapping joint permanent and variable loads	4	0.00
Stability	1	0.00
Simplified method	5	0.26

Design value of the bearing pressure resistance $\sigma_{R,d} = 350.00 \text{ kN/m}^2$
 $\sigma_{R,d} = 350.00 \text{ kN/m}^2$. The design value of bearing pressure resistance has been specified directly.

Simplified method Superposition

No.	N _d kN	a' m	b' m	σ_d kN/m ²	$\sigma_{R,d}$ kN/m ²	η
5	1800.0	4.00	5.00	90.00	350.00	0.26

The bearing pressure is influenced by partial safety factors.