

## Frilo Application: STS+ Single-span Steel Column

### Contents

Application options	2
Basis of calculation	3
Design values of the internal forces	3
Verification process	3
Analyses in the ultimate limit states	3
Analyses in the serviceability limit states	3
Load transfer	3
Basic parameters	4
Structural system	5
Loading	7
Standard loads / wizard	7
Vertical load	7
Head loads, horizontal	8
Head moments around y	8
Wind loads	9
Impact loads	9
Member loads	10
Appended hinged column	13
Remarks	13
Design and analysis	14
Verifications in the ultimate limit state	14
Limit states	14
Verifications in the serviceability limit state	14
Load transfer	14
Output	16
Frequently asked questions	17

### Basic Documentation – Overview

In addition to the individual program manuals, you will find basic explanations on the operation of the programs on our homepage [www.frilo.com](http://www.frilo.com) in the Campus-download-section.

*Tip: Go back - e.g. after a link to another chapter / document - in the PDF with the key combination "ALT" + "left arrow key".*

## Application options

### Design standards

The *STS+* application performs structural safety analyses in accordance with the model column method for columns of steel profile sections as per EC 3 (EN 1993-1-1) under planned (ec-)centric loading. The regulations of the National Annexes are taken into consideration.

- DIN EN 1993-1-1:2010/ 2015
- ÖNORM EN 1993-1-1:2007/2017
- BS EN 1993-1-1:2008
- PN EN 1993-1-1:2010

### Structural systems

The following structural systems are supported:

- Cantilever column
- Hinged column
- Column pinned on top and restrained on bottom
- Column restrained on top and on bottom
- General column (the supporting conditions can vary in the directions of the main axes)

### Loads

You can apply vertical and horizontal loading on the column system and define moments. You cannot define loading that produces planned torsion, however. Moreover, you can define appended hinged columns in the directions of the both main axes and optionally apply the self-weight of the column.

### Calculation

STS+ generates automatically the appropriate load cases and load case combinations in accordance with the defined actions and performs the necessary analyses, whereby the decisive load case combination is determined for each limit state.

### Interfaces to other applications

You can transfer the characteristic support reactions or the design values of the support reactions to the following software applications:

- FD+ Isolation Foundation
- FDB+ Block Foundation
- ST3 Hinged Column Base
- ST6 Restrained Column Base

If the real load conditions do not comply with the defined standard or the loading situation leads to planned torsion, you cannot use STS+ for the calculation. The *BTII+* application is available for this purpose.

If you have a valid licence for the *BTII+* (2nd Order Buckling Torsion Analyses) you can transfer the structural system from *STS+* to *BTII+* via the data export function. The *BTII+* application is also suitable for second order buckling torsion analyses of more complex systems.

## Basis of calculation

The basis of calculation of the *STS+* application is the Eurocode 3 standard series. The National Annexes for Austria and Great Britain are implemented in the current version of the application.

### Design values of the internal forces

The calculation of the internal forces for the decisive load combination is performed in a first-order analysis.

All necessary combinations of actions are automatically taken into account in accordance with the safety concept set forth in the Eurocode 0.

The decisive internal forces combinations in the ultimate limit state are calculated for the verification of the cross-sectional resistance and the stability verification of the component.

The user must specify the design situation on which the serviceability analyses should be based.

The internal forces combinations for the design values of the support reactions are determined in addition.

### Verification process

#### Analyses in the ultimate limit states

The load-bearing capacity verifications are based on the internal forces determined in a first-order analysis.

The stability verification of the component is based on the model column method. This analysis is preceded by a numerical calculation of the respective buckling load factors.

#### Analyses in the serviceability limit states

The serviceability verification refers exclusively to the calculation of the displacement, separately for the different main axis and the resultants.

Deformations are also calculated with internal forces determined in a first order analysis. You should keep in mind that deformations calculated in second-order analyses can be considerably greater in some cases. If the deformations are of particular importance, you should perform an advanced second order analysis. If you have a valid licence for *BTII+* you can use this application for this task

### Load transfer

The supporting forces of the column system can be [transferred](#) to the applications Isolated Foundation (*FD+*), Block Foundation (*FDB+*), Base Plate of Steel Column (*ST3*) and Restrained Base of Steel Column (*ST6*). You should note in this connection that the reaction forces are calculated in first order analyses.

## Basic parameters

### Standard and safety concept

**Design standard** selection of the relevant National Annex for the load-bearing capacity verification as per EC3.


**Snow as accidental loads** When you check this option, snow loads are also included as accidental action in addition to the typical design situations. The user can either specify a load factor for the accidental snow loads or have it determined automatically by the software.

**$\psi_2 = 0,5$**  Check this option to increase the value of the combination coefficient  $\psi_2$  to 0.5 in the accidental design situation under snow load. (See introductory decree of the federal states, e.g. Baden-Württemberg)

**Location in windzone 3/4** Check this option if the building is situated in wind zone 3 or 4. In this case, you need not consider snow as an accompanying action with wind being the leading action.

**Same  $\gamma_G$  for permanent loads** Check this option if all permanent loads or load cases shall be considered with the same partial safety factor ( $\gamma_{G,sup}$  or  $\gamma_{G,inf}$ ). Otherwise, all permanent loads or load cases are combined with each other with ' $\gamma_{G,sup}$ ' and ' $\gamma_{G,inf}$ '.

**Consequence class** allows you to define the consequence class the safety concept should be based on: CC1, CC2 or CC3.



### Structural safety

**Cross section design** The cross section design is optionally performed in accordance with the  
 - elastic or the  
 - plastic method as per Para. 6.2

**Model column verification** The verification in accordance with the model column method is based on 6.3.3 (annex A or B) or on 6.3.4

### Serviceability

**Design situation** defines the design situation for the verifications in the limit state of serviceability.

**Verification of the absolute imperfection (deformation)** performs the serviceability verification with consideration of the difference in deformation to the undeformed system.

**Absolute limit imperfection (deformation)** the permitted maximum absolute imperfection of the structural system.

**Verification of the relative imperfection (deformation)** performs the serviceability verification with regard to the effective lengths, which are determined by the turning points (moment passage) of the bending line.

**Relative limit imperfection (deformation)** the permitted maximum relative imperfection of the structural system.

## Structural system

### Material

Steel type the following steel types are currently available for selection:

Material	
Type of steel	structural steel
Steel grade	structural steel
System	normalized steel
	thermo steel
Type of support	weather-proof steel
	heat resisting steel
Height	thermof. hollow sect.
	hollow section N
Cross-section	user defined type

Steel grade the available options for the steel grade depend on the selected steel type.

Parameters if you have selected "user-defined steel type", you can display a dialog for the definition of the steel parameters by activating the button. Otherwise, the parameters of the selected steel are displayed in this section.

### Structural system

Column type: selection of the column system. Activating the button displays a selection dialog with graphical items.

Height height of the column in the x-direction.

Cross section activating the button displays a dialog for the selection of the steel shape.

The manipulation of this dialog is described for all software applications in the document "[Select - edit cross section](#)".

Only steel shapes that are approved for the model column method are displayed.

The screenshot shows the 'Properties' dialog box with the 'System' section expanded. The 'Type of support' is set to 'Pin-ended column', and the 'Height' is set to 'Pin-ended column'. The 'Material' section shows 'Type of steel' as 'structural steel' and 'Steel grade' as 'S235'. The 'Bearing top' and 'Bearing bottom' sections show displacement and rotation settings for y and z directions.


### Bearing top/bottom

Displacement... discrete supporting conditions for translation or rotation (in direction of/around the y- or z- axis):  
 Fixed: to enter a value remove the check mark:  
 0 = unsupported  
 > 0 = elastically supported

### Intermediate support in the y-direction

You can define lateral fasteners in this section. This allows you to simulate applying bracing (discrete supports) or plate-type stiffening structures (continuous supports).

*Note: The supports are generated with a very high default spring value that produces a quasi rigid support. If you like to define more refined springs you should use the BTII+ application. (See [interface to BTII+](#)).*





### Location of the support

It is of essential importance for the examination of the stability to define where the lateral supports apply to the cross section.

The selection list allows you to specify the point of application of the lateral support.

See also the drawings:



### Remarks


... about the system

activating the button displays a dialog where you can enter an explanatory text. Optionally, you can display or hide this text in the [output](#) (the corresponding options are enabled when you enter a text).

# Loading

## Standard loads / wizard

You can define the standard loads already in this section. The [wizard](#) ensures that you can generate a calculable basic system by defining a few parameters. You can customize this basic system subsequently.



## Vertical load


Value	Description	System sketch
Permanent	Permanent portion of the characteristic vertical load.	
Variable	Variable portion of the characteristic vertical load.	
Eccentricity	Eccentricity $e_y/e_z$ of the load application point in the y/z-direction (requires a sign)	

### Action group

The vertical loads are always classified as "imposed loads of class A". The action can be edited later in the load table.

## Head loads, horizontal


For cantilever columns

Value	Description	System sketch
Permanent in y-/z-direction	Permanent portion of the characteristic head load in the y-/z-direction.	
Variable in y-/z-direction	Variable portion of the characteristic head load in the y-/z-direction.	

### Action group

The horizontal loads are always classified as "imposed loads of class A".

## Head moments around y


Value	Description	System sketch
Permanent	Permanent portion of the characteristic head moment around the y-axis.	
Variable	Variable portion of the characteristic head moment around the y-axis.	

### Action group

The node moments applying at the column head are always classified as "imposed loads of class A".



## Wind loads

Value	Description	System sketch
Wind in y-direction	Characteristic value of the wind load in the y-direction.	
Wind in z-direction	Characteristic value of the wind load in the z-direction ( $wz,k$ ).	


### Action group

The wind loads are logically classified as "wind loads".

### Alternative group

The wind loads are assigned to the first free alternative group (normally AltGrp=1), which means that they apply alternatively.

## Impact loads

Value	Description	System sketch
Impact load	Nominal value of an accidental concentrated load in the y-/z-direction ( $Ay/Az$ )	
Application point	Application point $a$ of an accidental concentrated load, measured from the base point.	

### Action group

The impact loads are classified as "accidental actions".

### Self-weight

...consider automatically

if you activate this option, the self-weight of the column is taken into account automatically.

### Member loads

#### Loads

Enter the data of the first load case in the data-entry mask or directly in the load case table, which you can be display by activating the button.

To define another load, insert a new row first by activating the button.

	Load type	Direction	pi	pj	a	l	Load attack	Action	Zus	Alt	Descript
					[m]	[m]					
1	Head load	in x-dire	50.0	---	---	---	0/0	Permanent loads	0	0	
2	Head load	in x-dire	40.0	---	---	---	0/0	Cat. A: domestic, resident	0	0	
3	Head load		5.00	---	5.00	---		Permanent loads	0	0	
4	Continuous distr. load		0.0	0.0	0.00	0.00	top	Permanent loads	0	0	
5	Single load at a		10.00	---	5.00	---		Permanent loads	0	0	
6	Line load from a to a+l							Permanent loads	0	0	
	Triangular load over entire bar		5.0	---	---	---	Axis	Wind loads	0	1	
	Trapezoidal load over entire bar										

By clicking on the arrow icon you can access a load value summary - see the description of the LOAD+ application.


Load application point: selection of the load application point or the cross-section (top edge, bottom edge, component axis) or specification of y/z coordinates for the load eccentricity.

Alternative data entry in the FDC section: see also [Data entry via tables](#) (Basic Operating Instructions)


*Tip:* A description is displayed in the status line each time you click into a particular data-entry field.

Load type selection of a load type as described below.  $p_i, p_j$  are characteristic load values.


Linear load a linear load that applies constantly over the total height of the column.




Concentrated loads a concentrated load applying at the distance  $a$  from the base point.




Concentrated moment a moment applying at a distance  $a$ , measured from the base point




Line load from  $a$  to  $a+l$  a linear variable line load applying over the column height, starting at a distance  $a$  measured from the base point and extending over a length  $l$ . Enter the load values for the front end and the rear end of the load extension.



Triangular load over entire member variable triangular load applying over the entire column height.




Trapezoidal load over entire member variable trapezoidal load applying over the entire column height.



Direction selection of the direction of action. The loads or moments act in the direction of or around the global y-/z-axis. Concentrated loads also act in the direction of the x-axis.

**Load position** selection of the load position on the cross section (top edge/bottom edge, component axis) or input of the y / z coordinates for the eccentricity of the load.  
 You can display the corresponding dialog in the load table by activating the button.

**Action** category or kind of action of the load



**Concurrent group** assignment of the load to a group of loads acting jointly. The group is defined by a group number entered by the user. Loads that are assigned to the same concurrent group always apply simultaneously. Loads in a concurrent group must also be member of an action group.

**Alternative group** assignment of the load to a group of loads excluding each other. The group is defined by a group number entered by the user.


**Description** you can optionally enter a short note that appears in the output.

**Comments** allows you to enter personal comments on the loads. You can optionally hide or display these comments in the [output](#). The corresponding options are enabled when you enter a text.

**III.:**

*Principle representation of the concurrent and alternative groups.*

*Load 1 and 3 act together and are therefore assigned to the concurrent group 1. The same applies to load 2 and 4 (concurrent group 2). The concurrent groups 1 and 2 are assigned to the alternative group 1. Therefore, the loads of these two groups cannot apply simultaneously.*



## Appended hinged column

To handle cantilever columns, horizontal equivalent loads are generated for the appended hinged column


**Arrangement** direction of action of the appended hinged column is the y-/z-direction

**Height  $h$**  height of the appended hinged column

**Axial force  $Nd$**  design value of the vertical load acting on the appended hinged columns.

**Number** number of hinged columns appended in series

Appended hinged columns		
Hinged system	1/1	
Arrangement	in z-direction	
height	$h$ [m]	2.50
Axial force	$Nd$ [kN]	5.0
Number	1	
Remarks		
... Actions		



## Remarks

[... on the actions](#)

The option displays a dialog for the input of text. You can optionally include this text in the [output](#).

## Design and analysis

### Verifications in the ultimate limit state

#### Limit states

The analyses in the ultimate limit state include the following individual verifications:

- Analysis of the cross-sectional resistance with consideration of local buckling failure (verification of the  $c/t$ -limiting values and assignment to cross section classes).
- Verification of the plastic cross-sectional resistance as per EN 1996-1-1, para. 6.2.  
If you have activated the "Elastic design" option when defining the basic parameters, the verification is performed in accordance with the elastic method as per equation 6.1.
- Stability verification as per EN 1993-1-1, equation 6.3.

The stability analyses of lateral buckling and lateral torsional buckling are based on the so-called model column method.

When applying the simplified analysis, an eigenvalue calculation is performed using the subspace method. The eigenvalue determination for the FE problem requires the solution of the general matrix eigenvalue problem for the smallest eigenvalue  $\eta Ki$ . This task is handled in *STS+* via the calculation module of the *BTII+* application. The examination is performed for each load case combination and separately for each applicable design situation. This method ensures that the actually decisive failure situation in accordance with the safety concept can be determined.

### Verifications in the serviceability limit state

The displacements in direction of the different main axis and the resulting displacement are calculated in a first order analysis. The results are compared to the parameters defined by the user. The verification is considered successful when the calculated shifts are smaller or equal to the user-defined values.

#### Load transfer

The term load transfer refers basically to two extender functions, the transfer of the structural system to *BTII+* and the transfer of support reactions for the calculation of connected structures.

#### System transfer to the *BTII+* application


##### General

The first extender function is used for the export of the column system to the *BTII+* application for the calculation of more complex systems or to perform comparative calculations.

Higher requirements on the calculation of column systems which cannot be fulfilled by an application such as *STS+*, become relevant if the supporting conditions do not comply with the prescribed standard or if loads have to be included that produce planned torsion. Such systems cannot be verified using the model column method. They require second-order analyses with consideration of warping torsion. The *BTII+* application offers the necessary performance parameters for this task.

##### Exporting the structural system

The column system is represented as a system section in the *BTII+* application. The supporting conditions correspond to the structural system of the column including the lateral supports.



### Transferring supporting forces

*STS+* offers a load transfer feature to other applications for the calculation of connected structures and foundations.

An interface to the Isolated Foundation application *FD+ / FDB+* allows the user to use the support reactions of the column system for the analysis of the foundations immediately underneath, if this is required. After selection of the appropriate foundation application it is launched automatically and the loading is generated in the form of the individual load cases used in *STS+*. The user must simply add the foundation-specific details and check the transferred load values.

The interfaces to *ST3* and *ST6* allow the transfer of the characteristic support reactions for the calculation of pinned or restrained column base structures.

# Output

By checking or unchecking the various output options, you can define the scope of the output (if an option is checked, the associated contents is integrated in the output document)

The options are described by tooltips and explanatory notes in the information section on the bottom of the screen.

Scale of system graph by modifying the default scale you can adjust the size of the graph in the output document according to your requirements.

## Output as a PDF file

The Document tab displays the document in PDF. You can display, save and print the PDF document.

A general description of the output options is available in the document:

[Output and printing](#)

**Properties**

- Basic Parameters
- System
- Loads
- Design
- Output**

---

**General**

- Brief output
- Notes

**System**

- System- and load- graphics 2D
- System graphics 3D
- System graphics scale [1:] 50

**Loads**

- Actions

**Results**

- Support reaction- characteristic per load case
- Support reactions - design values

**FRILO Software GmbH**  
 Stuttgarter Str. 35 | Tel.: +49 711 810020 | Projekt: Localization  
 70469 Stuttgart | Fax: +49 711 858020 | Position: STS+001  
 04.05.2015 Seite: 2

**Load**

**Actions**

Id	Type	Situation	Name	γ <sub>acc</sub>	γ <sub>inf</sub>	ψ <sub>0</sub>	ψ <sub>1</sub>	ψ <sub>2</sub>
99	G	P/T	Permanent loads	1.35	1.00	1.00	1.00	1.00
1	Q	P/T	Cat. A: domestic, residential areas	1.50	0.00	0.70	0.50	0.30
5	Q	P/T	Wind loads	1.50	0.00	0.60	0.20	0.00

**Loads**

Type 14 = Head load kN      4 = Concentrated moment kNm  
 2 = Uniformly distributed load kN/m  
 The dead load is automatically taken into account.

Comments included in the output

No.	Type	in/about	p <sub>i</sub>	s	R	l	Act	Alt
1	14	x	50.0				Permanent loads	0
2	14	x	40.0				Cat. A: domestic, residential areas	0
3	4	y	5.00	5.00			Permanent loads	0
4	4	y	5.00	5.00			Permanent loads	0
5	4	z	10.00	5.00			Permanent loads	0
6	2	z	5.0				Wind loads	1



## Frequently asked questions

### Structural system

Can I also calculate multi-span systems in *STS+*?

No. *STS+* provides for the calculation of single-span columns only. However, you can define lateral supports in the form of discrete or continuous supports. The application point relevant for the stability analyses can be defined either on the upper or the lower flange or in the shear centre.

### Loads

Can I define loads that produce planned torsion?

No. Loads that produce planned torsion are not considered in *STS+*. The most important reason for this restriction is that the simplified model column analysis must not be used in a comparable load situation. In such a case, a second order analysis of torsional warping is required. We like to point out in this connection that our *BTII+* module is able to perform this task.

### Calculation

Can I perform a second order analysis in addition to the verification based on the ideal column method?

No. Systems requiring second order analyses can be calculated with our *BTII+* module.