

# Basement Wall – BWA+

## Contents

Application options	2
Basis of calculation	2
Data entry	3
Basic parameters	3
Structural system	4
Wall	4
Foundation	4
Soil	4
Ground surface/groundwater	5
Loads	6
Design	7
Output	8

## Application options

The BWA application allows the design of basement walls of reinforced concrete, which can be loaded by vertical loads and moments as well as earth pressure on one side.

At the same time, the program performs the simplified verification in accordance with DIN 1054:2015.

The bending design and shear design of the foundation are put out.

### Available standards


- DIN EN 1992
- BS EN 1992
- ÖNORM EN 1992
- EN 1992
- NTC 1992

Furthermore

- DIN 1045-1
- ÖNorm B4700

Foundation engineering standards:

- DIN 1054
- DIN EN 1997-1 in combination with DIN 1054:2015



### Structural system

- Ceiling - wall - foundation
- The floor above can have either have a pinned support or be partially or fully restrained.
- Concentrated loads applying to the wall top and the inner foundation border
- Concentrated moments applying at the wall top
- Structural load on the ground
- Slope
- Block loads
- Soil layers
- Water

## Basis of calculation


The basement wall is considered as a vertical member with a pinned or restrained top and a base restrained between two bedded members simulating the foundation.

## Data entry

The [wizard](#) is launched automatically when you start the application program. You can enter quickly the most important key figures of the frame system in the displayed window. These values can be edited subsequently in the input area or on the [interactive graphic user interface \(GUI\)](#).

### Basic parameters

Design standard	defines the design standard the structural safety analysis is based on. If you use Eurocodes and specify the national version the associated National Annex is also referred to.
Accidental snow load	you can select whether the snow loads should be considered as accidental action in addition to the normal design situations. You can either specify a load factor for the accidental snow loads or have it determined automatically by the software.
Load factor for snow	toggles between automatic and user-defined determination of the load factor that should be used to include snow load as an accidental action relative to its characteristic value.
$\psi_2$	you can select whether the combination coefficient $\psi_2$ in the seismic design situation (AE) should be raised to the value 0.5 for the snow action. (See introductory decrees of the German federal states, e. g. Baden-Württemberg).
same $\gamma_G$ ...	you can select whether all permanent loads and/or load cases should be considered with the same partial safety factor ( $\gamma_{G,sup}$ or $\gamma_{G,inf}$ ). Otherwise, all permanent loads and/or load cases are combined with each other using $\gamma_{G,sup}$ and $\gamma_{G,inf}$
Remarks	you can call up a data-entry field for the comment text.



## Structural system

### Wall

You can define the material and the dimensions (height, thickness, projection) for the wall as well as the corresponding parameters for the floor above ("Ceiling" button).

**Projection** distance from the outer edge of the foundation to the outer face of the wall.

**Wall friction angle  $\delta$**  friction angle  $\delta$  between wall and soil.  $\delta$  is in the range  $-1 \cdot \varphi'$  and  $+1 \cdot \varphi'$ .  $\pm 0\varphi'$ ,  $1/3\varphi'$ ,  $2/3\varphi'$  or  $3/3\varphi'$  are offered for selection or you can enter a coefficient  $-1.00$  to  $1.00 - \varphi'$  via "Input".

### Foundation

You can define the material and dimensions for the foundation and the value for the subgrade reaction modulus  $cb$ .

### Soil


#### Soil properties

**Determination  $\sigma_{R,d}$**  select whether to define the design value of the base pressure resistance by entering a user-defined value or by taking a value from a standard table or from a self-defined table - see the paragraph below.

**Base pressure resistance** permissible base pressure  $\sigma_{R,d}$

#### Soil layers

You can define several soil layers.

You can create an additional soil layer using the  icon.

See also the chapter "Data entry via tables" in the document [Basic Operating Instructions-PLUS.pdf](#)

Alternatively, you can also display the entered data on the "Soil layers" tab below the GUI in the form of a well-structured table.

**Specific weight**  $\gamma$  specific weight of the soil.

**Specific weight under buoyancy**  $\gamma'$  specific weight of the soil layer under buoyancy. Define [groundwater](#) to enable this data-entry field.

**Friction angle**  $\varphi'$  friction angle of the soil in this layer.

**Cohesion**  $c'$  soil cohesion.

**Thickness**  $d$  thickness of the soil layer

**Designation** you can optionally specify a name for the soil layer.



Properties			
Basic Parameters			
System			
Wall			
Foundation			
Ground			
Terrain/Ground water			
Loads			
Design			
Ausgabe			
Wand			
Concrete		C 25/30	
Reinforcement Steel		B500B	
Height	hW	[m]	2.80
Thickness	dW	[m]	0.24
Overhang left		[m]	0.30
Wandreibungswinkel $\delta$			0 $\varphi'$
Decke			Decke

Determination	$\sigma_{R,d}$	direct specificatio
Bearing pressure resistance	$\sigma_{R,d}$	direct specification DIN 1054:2015 A2 From own table
Soil layers 1/1		
Stroke weight	$\gamma$	[kN/m <sup>3</sup> ] 18.00
Buoyant unit weight	$\gamma'$	[kN/m <sup>3</sup> ] 8.00
Effective friction angle	$\varphi'$	[°] 30.0
Cohesion	$c'$	[kN/m <sup>2</sup> ] 0.00
Thickness	$d$	[m] 4.00
Description		

## Ground surface/groundwater

### Ground surface

Height of earthfill $h_e$		height of the earthfill measured from the base of the wall.
Slope	without	no inclination i.e. no slope;
	continuous	the slope has a uniform inclination;
	discontinuous	the slope can be divided into several sections with different inclinations.
Inclination		enter the inclination angle of a continuous slope.


### Slope sections

If you have selected a discontinuous slope, you can define the individual sections and their inclination in this dialog box.

For basic information concerning the data entry via tables: see [Data entry via tables](#) (Basic Operating Instructions).

### Groundwater

If this option is selected, a groundwater load is assumed. Specification of the groundwater level measured from the upper edge.



The screenshot shows the 'Properties' dialog box with a tree view on the left and a table on the right. The tree view includes 'Basic Parameters', 'System', 'Wall', 'Foundation', 'Ground', 'Terrain/Ground water', 'Loads', 'Design', and 'Ausgabe'. The 'Terrain/Ground water' section is expanded, showing a table with the following data:

Gelände	
Height of earth filling	he [m] 3.00
Slope	without
Grundwasser	
Ground water	<input checked="" type="checkbox"/>
Ground water level	[m] 0.00
Water level in basement	<input type="checkbox"/>

## Loads


Self-weight                      automatic consideration of the self-weight.

### Ground loads

You can define several ground loads in the dialog box or via the "Ground loads" tab below the GUI.

See also the chapter "Data entry via tables" in the document

[Basic Operating Instructions-PLUS.pdf](#)

Load type	area load, strip load, block load or line load.
Load value $p_i$	enter the load value or call up the load value summary via the "arrow symbol"  -
Distance $a$	distance from the wall edge.
Length $l$	load length parallel to the wall.
Width $b$	load width perpendicular to the wall.
Application depth $z$	distance of the load in the z-direction from the ground top level (values below ground are negative).
Earth pressure distribution	in combination with limited live loads, you can select either a rectangular or a trapezoidal load distribution in accordance with EAB (Recommendations of the Construction Pits Working Group). The ordinates of the trapezoidal distribution result from a linear interpolation that depends on the distance to the wall and the width of the load.
Action	assignment of an action to this load.
Concurrency group	the loads of a concurrency group always apply simultaneously. A concurrency group is defined by the number (0, 1, 2, ...) that is assigned to it.
Alternative group	various variable load cases with the same actions can be grouped into an alternative load case group by assigning an <u>alternative group number</u> to them. Only the decisive load case of this alternative load case group is invoked in the superposition.

### Top loads

You can define concentrated loads / concentrated moments applying on the wall top.

### Foundation loads

You can define concentrated loads applying on the foundation.

## Design

Minimum reinforcement	ductility reinforcement in accordance with DIN EN 1992-1-1, 9.2.1.1 (1).
Shear force as slab	performs the shear resistance verification for a slab instead of a beam, also with a beam cross-section.
Design at support face	the bending design of the foundation can be carried out either in the wall axis or in the support face of the wall.

### Earth pressure

Type of earth pressure	the earth pressure can be calculated either for the active state or for the state at rest.
Compaction earth pressure	if soil is filled layer by layer and then compacted intensively the earth pressure due to compaction will exceed the earth pressure caused by the self-weight of the soil.
Settings	<p>the parameters for the compaction earth pressure are displayed.</p> <p>In accordance with</p> <ul style="list-style-type: none"> <li>- DIN 4085 intensive / light,</li> <li>- ÖNorm B 4434.</li> </ul> <p>The compaction earth pressure for strong compaction is calculated as per DIN 4085. For light compaction (vibrating plate with an operating mass of up to 250 kg) "light" should be selected. Alternatively, you can include the compaction earth pressure as per ÖNorm in addition to the earth pressure at rest.</p> <ul style="list-style-type: none"> <li>- Compaction width <math>B</math>: Width of the space to be filled. <math>B</math> has only an influence in combination with earth pressure at rest and increased active earth pressure (with low-yielding walls).</li> <li>- Curved sliding surfaces: The depth from which the full compaction earth pressure is considered is determined by comparing the compaction earth pressure to the passive earth pressure. The associated passive earth pressure coefficient can be determined if linear and curved planes of rupture are assumed.</li> <li>- Yielding of the wall: value displayed for information. It is automatically determined and depends on the type of earth pressure.</li> </ul>

### Reinforcement foundation / wall

You can define the concrete cover, the reinforcement layer, the minimum diameter and the [durability](#).

Read the information displayed in the info area.

## Output


### Scope of the output and options

By activating the corresponding options, you can define the scope of the output.

### Output as a PDF document

On the "Document" tab, a PDF document is displayed.

See also the document "[Output and Printing](#)".



The screenshot shows the 'Document' tab in the software interface. The main content area displays a PDF document with the following technical data:

**FRILO Software GmbH**  
 Stuttgarter Str. 40 Phone: +49 711 810020 Fax: +49 711 858020  
 70469 Stuttgart Item: (New item) 11/6/2019

**Slab**

Concrete	Reinforcement Steel	$E_c$ [N/mm <sup>2</sup> ]	$d_s$ [m]	$L_1$ [m]	$EI/L$
C 25/30	B500B	31000	0.20	3.00	0.00

**Wall**

Concrete	Reinforcement Steel	$h_w$ [m]	$d_w$ [m]	$O_{ve}$ [m]
C 25/30	B500B	2.80	0.24	0.30

**Foundation**  
 Concrete = C 25/30  
 Reinforcement Steel = B500B  
 Height = 0.80 m  
 Width = 1.14 m  
 $C_b$  = 10000 kN/m<sup>2</sup> Bedding module

**Terrain**  
 horizontal terrain  
 Height of earth filling  $h_e$  = 3.00 m above the upper edge of the foundation

**Water**  
 Ground water level = 0.00 m under top edge terrain

**Soil layers**

$\gamma$ [kN/m <sup>3</sup> ]	$\gamma'$ [kN/m <sup>3</sup> ]	$\phi'$ [°]	$c'$ [kN/m <sup>2</sup> ]	$d$ [m]	Description
18.00	8.00	30.0	0.00	4.00	

**Earth pressure**  
 Earth pressure type = Earth pressure at rest  
 Any tensile forces from cohesion are not applied.  
 Wandreibungswinkel  $\delta = 0 \phi'$

**Load case**  
**Actions (Act)**